

Manual

Introduction

Using the packages follows at own risk. **flashclub** sound design is not responsible for the loss of data, disfunction arising through the use of the products.

Please read this manual carefully, to avoid this.

Warning

Hardware and storage

To load the sound-expansions you need an external harddrive for example for CD's or a USB- or SD-slot, because the files are too big for normal floppy discs.

RAM

The **FSD**-Packages are created with a maximum of 32 MB. Unfortunately the Kurzweil K2600 comes only with 16 MB RAM. We recommend you to expand your RAM. If you struggle with that, just contact us. We will help you.

Installation

- 1) Unzip the zipped data on your computer.
- 2) Copy them on suitable storage.
- 3) Connect this storage to your Kurzweil K2600.
- 4) Now search for it over the menu to load the data into your instrument.

The time of the loading process depends on the size of the file.

Copyright notice

The sound extensions are protected and all rights are reserved. After purchasing the sound extension, you will receive a license to freely use the sounds in your music. Private as well as commercial. After purchasing and using the Sound extension, you accept the license agreement of **flashclub** sound design. Copying the sound enhancements or passing them on to third parties is strictly prohibited and will be prosecuted. All samples were newly recorded and programmed for the respective devices.

Kurzweil is registered brand of the HDC Young Chang R&D Institute based in the USA.